

TYRO79 Vtx Setting:

- Long Press Button 2S, entering into CH Setting Mode.
- Red Light flash 1 time, Blue Light flash 1-8 time (CH1-CH8). At this time , a short press of the key CH plus 1 will flash corresponding number of times. CH1-8 cycle.
- Then, Long Press 2S again, entering into Band Setting Mode.Red Light flash 2 times, Blue Light flash 1-5 time (A-B-E-FS-Race Band).
- Long Press 2S once again, entering into Power Setting Mode. Red Light flash 3 times, Blue Light flash 1-4 times (Power 25mW- 100mW-200mW-300mW)
- Finally, Long Press 2S, Logout setting mode. Or it will logout automatically while no operation after 30S.

Band	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Band-A	5865	5845	5825	5805	5785	5765	5745	5725
Band-b	5733	5752	5771	5790	5809	5828	5847	5866
Band-E	5705	5685	5665	5665	5885	5905	5905	5905
Band-F	5740	5760	5780	5800	5820	5840	5860	5880
Band-r	5658	5695	5732	5769	5806	5843	5880	5917

Note: In the remote control, the power of 25 corresponds to the actual 25 mW, 200 corresponds to the actual 100 mW, and 500/800 corresponds to the actual 200 mW.